

Installation Instruction:

1. Separate the inside (1, 2, 3, 4) and the outside (5, 6, 7, 8, 9, 10).
2. Put the inside (1, 2, 3, 4) and the outside (5, 6, 7, 8, 9) on both sides of the sink.
3. Use the locknut (7) to fasten both sides.
4. Insert the screener (1) (2) into the stainless steel bowl (3).

